

How to upgrade PV-800 firmware

1. Prepare a SD card and format it before save the firmware to it.
2. Copy the firmware files to the root directory of the SD card.

Note: As our engineers are always updating and improving the firmware, your device's firmware may have a slightly different filename than presented in this instruction.

3. Attach the PV-800 to AC power adapter & power on the PV-800.
4. In the main menu go "Program Setting "



5. Scroll down until you see "Firmware Upgrade"



6. Select OK in the “Firmware Upgrade” menu. When upgrade completed the PV-800 will reboot itself.

