

HD 1080P Clear Eye Glasses Covert Hidden Camera WiFi IP Quick Guide

Charging Your Camera

Using the included USB cable and wall charger, please charge the camera for at least 2 hours. The LED on the camera will turn green when connected to power.

Recording with your Camera

The camera requires the use of a Micro SD card up to 128GB. Before turning your camera on, please insert your Micro SD card into the camera.

To turn the camera on short press the power button. You will see the blue and red LED turn on simultaneously. Once you see the blue and red LED start to flash, you can connect to the camera's WiFi and use the phone app.