

PATROLEYES Edge




USER MANUAL


OVERVIEW







OVERVIEW



The EDGE body camera is an advanced recording system with many options and features available. Please review the manual to familiarize yourself with the functions of this camera.

Troubleshooting: If you are having problems with your camera, please first fully charge it and power it on, then press the reset button. Pressing the reset button will force the camera to shut off. Press the power button to turn the device back on and your device should now be working properly.

Note: Resetting the device will not delete any files on the camera.

BEFORE USE

Fully charge the camera using the included USB cable and charging dock for 3-4 hours. The charging indicator will turn blue when charging. When the device is fully charged, the blue light will turn off.

Confirm that the date and time on your device are correct and enter your device ID and badge ID through the camera setup menu.

Wearing your Body Camera Properly

On your chest (uniform):

Attach the camera clip to the front of your uniform. Rotate the camera clip 45° and clip it to the top of your uniform.

On your shoulder:

Using the optional epaulette mount, clip the camera to the bracket on the mount and attach the mount to your uniform.

KlickFast Mounts:
Optional magnet, molle, and epaulette mounts now available.

Basic Operation

Power ON: Press the power button to turn on the camera and enter into Preview Mode. The green LED on the top of the camera will turn on.

Power OFF: Press and hold the power button to turn the camera off. Before shutting down, any video being recorded will be saved.

GETTING STARTED

LED Indicators

Charging Indicator: Blue = Charging (will turn off when fully

charged)

Activity Indicator: Red and Blue = Recording + Charging

Solid Red = Recording

Green = Standby

Blinking Red = Pre/Post Event recording

Transferring files to your computer:

(compatible with Windows XP, Vista, 7, 8, 10 & Mac)

1. Connect your camera to your PC by directly connecting the USB cable to your camera or by putting the camera into the docking station. Make sure your camera is on.

2. Enter the password on the device. The default password is 888888.

3. Navigate to "My Computer" and you will see the camera show as a removable device. Usually the E, F or G drive.

folder and then double click on the 100MEDIA folder and you will see a list of all files recorded.

5. Select all the files on your camera you would like to copy to

4. After clicking on the removable drive, double click on the DCIM

your computer. After the files have been copied to your computer feel free to delete the files still on your camera to free up storage space.

RECORDING

Video Recording

In Preview Mode, single-press the record button to start recording video, press the button again to stop recording. When recording the Red LED indicator on the top of the camera will be solid red

One Touch Recording

When the unit is powered off, press and hold the record button for 2 seconds. The device will turn on and automatically record.

File Tagging

While video recording, press the file tag button. A warning icon (^) will appear on the LCD. The video will be saved in the "Event" folder. To cancel file tagging, press and hold the function button until the warning icon is removed.

Audio Recording

In Preview Mode, single-press the audio button to record an audio file, press again to stop recording.

Photograph Feature

In Preview Mode, single-press the photo button, and the unit will start taking pictures.

To capture a picture while video is being recorded, singlepress the photo button.

SYSTEM SETTINGS

Switch Between Video Recording and Audio Recording

When video is being recorded, press the audio record button to stop recording video and start audio recording, the video will be saved.

When an audio file is being recorded, press the video record button to stop audio recording and start video recording, the audio file will be saved.

Playback

Press the back button and you will see Video, Photo, Audio. Use the up/down buttons to select the category and then press the confirm button to enter the media directory. Use the up and down buttons to navigate your files and press the "confirm" button to view the file. Pressing the up/down buttons will allow you to fast forward or rewind the video. Up to x64 speed.

Settings for Video Recording

In Preview Mode, single-press the menu button to enter the camera's main menu and press the menu button again to enter the Video Settings.

Flashlight LED Light

Press and hold the flashlight button for 2 seconds to turn on the flashlight LED. The light will provide minor illumination to improve image quality when necessary. Press and hold the flashlight button again to turn the flashlight LED off.

VIDEO SETTINGS

In preview mode, press the menu button to enter into setup menu, select the first icon and press the confirm button.

Resolution

There are six options to select from:

1440p@30fps / 1080p@60fps / 1080p@30fps / 720p@60fps / 720p@30fps / 480p@30fps

Video Quality

There are three options to select from:

High / Medium / Low

This refers to the video bitrate. The higher the setting, the better the video quality and the larger the video size.

Video Lenath

There are five options to select from:

Off / 2 min / 5 min / 10 min / 15 min

Video length refers to the length of video segments while the device is recording. The minute amount is the length of each video segment before device begins a new video file. This will NOT stop device from recording, it will just split your videos

H.265 Encoding

There are two options to select from:

into smaller, more manageable files.

Off / On

H.265 saves over 50% on storage space, and improves video quality.

VIDEO SETTINGS

Photo Size

There are six options to select from: 4M / 8M / 12M / 16M / 32M / 40M

Burst Mode

There are eight options to select from:

Off / 2 / 3 / 5 / 10 / 15 / 20 / 30

Pre-record

There are two options to select from: Off / On

Post-record

There are six options to select from:

Off / 5 sec / 10 sec / 20 sec / 30 sec / 60 sec

Mute Recording

There are three options to select from:

Off / Pre-recording / On

Audio won't be recorded when mute recording is on.

Record Notification

There are six options to select from:

On / 5 sec / 10 sec / 15 sec / 30 sec / 60 sec

When enabled, the body camera will vibrate and beep at the set intervals

SYSTEM SETTINGS

Connection Mode

There are two options to select from:

Password Mode / Software Mode

Password mode means to enter the password on the camera after connected to PC to view data in camera. Default password is 888888.

Software mode means to use CamManager after the camera is connected to PC to view data in camera. See page 13 for more information.

LCD Brightness

There are multiple options to select from:

1-10: 1 being the dimmest and 10 being the brightest.

LCD Auto Off

There are six options to select from:

Off / 10 sec / 30 sec / 1 min / 3 min / 5 min

LCD Auto Off will turn off the LCD display of the camera when it has been in standby mode for the selected interval. This will NOT power off the device.

Key Tone

There are two options to select from:

On / Off

When enabled the camera will emit a beep every time a button is pressed.

SYSTEM SETTINGS

Vibration

There are two options to select from: On / Off

IR Filter

- Inter

There are four options to select from:

Off / Manual / Auto / During Recording
Off = The infrared lights will not be active.

Off = The infrared lights will not be active.

Manual = The Manual IR button must be pressed manually to

Auto = The IR lights will be turned on/off automatically once the amount of light becomes too low for daytime recording.

During Recording = The IR lights will be turned on/off automatically during recording.

Auto Power Off

turn on/off IR

There are seven options to select from:

Off / 30 sec / 1 min / 3 min / 5 min / 10 min / 30 min Auto Power Off will only power off the device when it has been

in standby mode for the selected interval. This will NOT power off the device during recordings.

Enhanced Standby

There are two options to select from:

On / Off

Enhanced Standby puts the camera into a low power usage state which enables the camera to be instantly powered on and begin recording.

SYSTEM SETTINGS

In preview mode, press the menu button to enter the setup menu, select the second icon and press confirm button.

GPS

There are two options to select from: On/Off

GPS Alert

There are two options to select from:

Off / Beep

When enabled, the camera will beep when a GPS signal is achieved.

Time Zone

There is a range of numbers to select from. The GPS will change the date and time accordingly. For example, New York City is EST and will be set to UTC-4.0. Central time zones are UTC-3.0.

Auto Update Time

There are two options to select from:

Off / On

Note: Will set the date and time via GPS

Date Format

There are three options to select from:
DD-MM-YYYY / MM-DD-YYYY / YYYY-MM-DD

Date & Time

Allows the user to change the date and time on the camera. You must enter your current password first to edit the date and time.

SYSTEM SETTINGS

Volume

Controls the camera's internal speaker. 10 being the highest and 1 being the lowest.

Recording Alert Type

There are three options to select from:

Off / Beep / Voice

When enabled, the camera will give either a beep or a voice command stating the camera is recording.

LED Indicators

There are two options to select from:

On / Off

Disables the top LED indicators on the camera.

Stealth Mode

There are two options to select from:

On/Off

Stealth Mode puts your camera into a special mode where no LED lights or audible notifications are enabled.

Change Password

Allows you to change your password. You must enter your current password to change the password.

Change Device ID

Allows you to change your device ID. You must enter your current password to change the password.

SYSTEM SETTINGS

Change User ID

Allows you to change your User ID. You must enter your current password to change the password.

Restore Defaults

Restores all camera settings to default. You must enter your current password to restore the camera.

ABOUT THIS DEVICE

Location System Info

When GPS is enabled this screen allows you to see the GPS status in detail.

Cam Manager

PatrolEyes Cam Manager is a desktop application that allows you to transfer files and edit certain settings on your camera. You can download the latest version from our FAQ page at:

www.stuntcams.com/edge

To login to Cam Manager first connect your camera to your PC. Once connected, select the user Administrator and enter the default password of 888888 and press Login. Once logged in you can use the drop down menus to select your settings. Once your settings are set, simply exit the program and your changes will be saved.

CAM MANAGER

Device ID & Police ID

The device ID can be up to 5 characters long while the Police ID can be up to 6 characters long.

Firmware Version:

Shows the current firmware verison of the camera. For firmware updates please visit patroleyes.com/edge-faqs

Username:

Assigns a username to the camera.

Watermark:

Allows the user to set a custom watermark on the video up to 20 characters long.

Sync PC Date/Time:

Snycs the cameras date and time with that of the PC.

Default Settings:

Will reset all camera settings to default.

Format Disk:

Will erase all data on the camera

Open File Explorer:

Allows you to access the camera storage to view evidence.

DROP-IN CHARGING CRADLE & ACCESSORIES

The included drop-in charging cradle allows you to charge the camera and transfer data.

Connect the USB charger to the cradle, and the red light on the dock will turn on. Insert the camera by pushing the camera into the cradle until it clicks into place. The camera will then start charging.

For transferring data, make sure the camera is in the USB Mode menu setting before connecting the camera to the cradle.

Optional Accessories:

Please take some time to review our most popular add on products below, which will help manage all of your cameras data and also protect your investment.

- •PatrolEyes 8 camera data transfer & charging station
- PatrolEyes protection plus program
 PatrolEyes magnet mount camera clips
- PatrolEyes drop lock mount
- PatrolEyes suction cup mount

Managing your cameras data:

PatrolEyes digital evidence management software (local only)

support@patroleyes.com

- PatrolEyes advanced cloud storage & management (cloud)
 PatrolEyes automatic video redaction software (14 day trial)
- We also have a wide variety of PatrolEyes accessories available here: www.stuntcams.com/patroleyesone Need further assistance - please call or email us at

Need further assistance - please call or email us at support@patroleyes.com

SOCIAL MEDIA

For a complete list of accessories and pricing visit:

www.stuntcams.com/patrolevesone

For the latest news and firmware upgrades, please follow us at: www.facebook.com/patroleyes www.twitter.com/patroleyes